

## **Adding or Programming Keys without a Recognized Remote Transmitter**

If there are no currently recognized transmitters available, follow this procedure to program transmitters. This procedure will take approximately 30 minutes to complete. The vehicle must be off and all of the transmitters you wish to program must be with you. The remotes must have the mechanical key cut to match the car before you can begin this process.

1. Insert the vehicle key of the transmitter into the key lock cylinder located on the outside of the driver door and turn the key to the unlock position five times within ten seconds. The Driver Information Center (DIC) displays Remote Learn Pending, Please Wait.

2. Wait for ten minutes until the DIC displays Press Engine Start Button to Learn and then press the ignition. The DIC displays will again show Remote Learn Pending, Please Wait.

3. Repeat Step 2 two additional times. After the third time all previously known transmitters will no longer work with the vehicle. Remaining transmitters can be relearned during the next steps. The DIC display should now show Ready for Remote # 1.

4. Place the new transmitter into the transmitter pocket. The transmitter pocket is located inside the center console storage area.

5. Press the ignition. When the transmitter is learned the DIC will display that it is ready to program the next transmitter.

6. Remove the transmitter from the transmitter pocket and press the unlock button. To program additional transmitters, repeat Steps 4 through 6. When all additional transmitters are programmed, press and hold the ignition for 5 seconds to exit programming mode.